

WATERPROOF BURIAL GRADE WIRE SPLICES!

SUPERIOR WATERPROOF WIRE SPLICERS insure that you get the best connection possible on your pet fence wire splices. **To use:**

1. Push the two ends of the wires into the outer two holes in the splice. View from the bottom to make sure the wires are fully inserted.







2. Using pliers squeeze the top black button down solidly until it bottoms out.







Additional splices are available from www.hightechpet.com