



Humane Contain Yard Staples



**for Above Ground
Boundary Wire Installation**

INSTRUCTION BOOKLET

INSTRUCTIONS

1. Run your twisted wire from your transmitter out to the beginning of your boundary.
2. Staple the twisted wire to the ground by hammering in a wire staple every 5 - 6 feet, making sure it is completely flush to the ground.
3. if you have a splice in your twisted wire, dig a small hole about 2 inches deep and bury the splice, placing a staple on either side of it to relieve any pressure on the spliced area.
4. Stand back and view the wire. If you see any raised areas, add staples where necessary.
5. Place a staple where the twisted wire and the beginning of the boundary meet.
6. Walk the wire to the first corner of your boundary and "Staple" it to the ground. Repeat this step for all four corners of your boundary.
7. Go back just as you did with your twisted wire and "Staple" any raised areas down until they are completely flush with the ground.

Your boundary wire is now installed using the simple High Tech Pet Boundary Wire Staples.

NOTE: For the next several days, until you see that the grass has fully grown over the boundary wire, hiding it completely from view, mow your lawn with care, making sure you avoid mowing over the boundary wire.



High Tech Pet Products, Inc.

2476 Palma Drive, Suite A

Ventura, CA 93003

www.hightechpet.com

Rev. I – 7/1/2011

ys-50-manual