

The New High Tech SOUND BARRIER™ is designed to help keep your pet out of areas where it is not allowed. It consists of an alarm unit and a special ultrasonic collar. The alarm unit automatically emits a high pitched tone in response to the presence of the ultrasonic collar. This harmless tone, which sounds somewhat like a smoke alarm, will be irritating to your pet and will drive it away from the restricted area.

Your High Tech SOUND BARRIER kit includes an alarm unit and an ultrasonic collar. The alarm unit requires a standard 9-volt battery (not included). The ultrasonic collar operates on a single B-3VA lithium coin cell which is included and installed.

Ultrasonic Collar

To energize collar, remove PULL tab and discard.

Testing the Battery

On the front of the ultrasonic collar there is a TEST button. The battery may be tested manually by depressing the TEST button. While the button is depressed, the LED will illuminate brightly. If the LED is dim, battery replacement is necessary.

Replacing the Collar Battery

The battery in your ultrasonic collar will last up to three months. To replace a worn out battery, follow the steps below.

- A. Insert screwdriver or knife in end slot and pry open.
- B. Separate top from bottom.
- C. Replace battery in top with the metal ring visible.
- D. Carefully mate top and bottom while keeping aluminum speaker centered in the top hole. Squeeze together the top and bottom until both ends snap.

Order replacement B-3V1A batteries now. Your pet will thank you!

Alarm Unit

Activating the Unit

To activate the alarm unit, remove the battery compartment cover, install a standard 9-volt transistor battery and replace the cover. The unit will remain on until the battery runs down or is removed.

Placement

Place your High Tech SOUND BARRIER alarm unit anywhere you wish to keep off limits from your pet. Typical examples are the living room couch or, chairs, kitchen table or counter, bed or just inside the door of a room.

Range Adjustment

The adjustment dial on the right front panel allows you to determine the distance from the collar at which the alarm unit will activate. Turning the dial fully clockwise will set the range at thirty (30) feet or more. The unit will be most sensitive when the collar is directly in front. Range will begin to decrease as the collar moves to either side. Turning the range dial counter clockwise decreases the range.

To achieve the most desirable range, place the collar at the desired distance from the alarm unit, then gradually increase the range, turning in a clockwise direction until the alarm sounds.

The alarm will remain "on" for five to ten seconds after the signal is removed. If the unit should begin to activate without the collar being present, this means that there is an alternate source of 40 Khz ultrasound somewhere nearby and the range setting should be reduced.

Testing the Alarm Battery

The test button on the left front panel allows you to test the alarm unit battery. The alarm will sound upon pressing the button indicating that the battery is good. If the alarm does not sound or appears weak, this indicates that the battery should be replaced. Be sure to replace with an ALKALINE battery.

Training Your Pet With the SOUND BARRIER

In many cases, using your new High Tech SOUND BARRIER will induce an immediate response from your pet and training is automatic. However, the unit is designed to assist you in training your dog or cat by providing a consistent training stimulus. It will also automatically reinforce your training when you are not present. In most cases, however, you must undertake a persistent training program with your pet.

1. Place the alarm unit in the desired location.
2. Escort your pet into the restricted area.
3. When you hear the alarm sound, immediately escort your pet from the restricted area along with a stern verbal "NO!"

This should be repeated at least ten times per training session and these sessions should continue for several days or weeks until your pet responds by leaving the area on its own.

You will find that even in the toughest of cases, use of the High Tech SOUND BARRIER will reduce training time and provide persistent and automatic reinforcement.

We will immediately replace the unit with a new one. We require that the defective unit be returned to our factory at the above address. Please do not return the product to the place of purchase for replacement. Some retailers and mail order catalogs offer cash refunds for defective merchandise. If you wish to return your product for refund rather than a new replacement unit and the place of purchase has a cash refund policy, we require that you first call our offices for a Return Authorization Code at: 1 (805) 644-1797

Your return authorization code must be provided to the retailer when you return your unit for refund.

High Tech Pet Products
2476-A Palma Drive
Ventura, CA 93003

FULL ONE YEAR WARRANTY

Your High Tech SOUND BARRIER is fully warranted for a period of one year. To validate this warranty, please fill out and return the warranty registration card that came in the package with your SOUND BARRIER unit.

If for any reason during the warranty period your SOUND BARRIER fails to work as advertised, simply return the unit to:



High Tech Pet Products, Inc.
 2476 Palma Drive, Suite A
 Ventura, CA 93003
www.hightechpet.com



SOUND BARRIER



INDOOR WIRELESS SONIC FENCE

OPERATING INSTRUCTIONS